

My Risycor CXI is not coming online, what can I do?

Check if the Risycor's firmware is up-to-date and if your network settings are correct.

Check the firmware version of your Risycor.

You can do this via the Resus PC Dashboard. If a new firmware is available, update your Risycor. Click [here](#) for the steps how to update.

Check your network settings.

Make sure all network settings comply with our [IT-specifications](#).